



## Easy mounting instruction

For magnetic glass board


The board is supplied inclusive screws, plugs and drilling template.




1.
There is metal on the back of the glass board.
The metal back is prepared with holes.




Attach the drill template to the wall with tape.




**3.** Drill two holes through the template.



4. Put the plugs into the holes.



...and screw in the screws.



6. Hang the board on the screws. Your glass board is ready for use!



Watch video Scan QR-code and see easy installation.



Please note that you can only use Super Strong magnets on your glass board. The magnet has to attach to the metal through the glass.

## Using a NAGA marker

The NAGA marker is based on liquid chalk and colour pigment. Inside the marker is a flexible spring for adjustment of the chalk and the colour. The inner spring must be activated before you can use the marker. The NAGA marker is water based and easy to wipe of, when it is dry. Use cloth or board eraser.



First time use of the marker, hold in vertical position on a sheet of paper, press down on nib for a few seconds to allow the ink to flow out until the nib absorbs the ink.

Shake well with cap on, before usage, to mix inner ink with color pigment.



After use, replace cap tightly. If nib become dry when using, shake marker to mix inner fluid and repeat process of pressing down on nib again.



www.naga.dk