


One-O-Matic

Product and assembly information

The **One-O-Matic** is best assembled using screws in the two holes on the back piece. It can also be assembled on an existing holder or by using the enclosed holder, made of polystyrene.

*Always make sure to put a screw in the top hole, in order to have the **One-O-Matic** steadily attached to the wall and to make sure that it is not easily removed.*



The **One-O-Matic** cup dispenser is made of polystyrene, a plastic material that can be recycled, or burned to be extract energy. Please observe that the **One-O-Matic** also contains steal springs that needs to be removed before the recycling of the plastic material.

The **One-O-Matic** is intended to be filled with Duni plastic cups.

The **One-O-Matic** can be cleaned using common detergent which does not contain solvent, acids or bases.